

REPLACEMENT SHEET

5/5

FIG 7

COMP TA

DP Slave Properties

General Configuration Cross-Traffic Overview

Slot	Type	Address	Typ	PROFIBUS Partner	E/A-Address	Length
4	Actual Value	PZD 1	Input	2	260	4 V
5	Setpoint	PZD 1	Output	2	260	4 V
6	Axis Separator					
7	Actual Value	PZD 1	Input	2	256	2 V
8	Setpoint	PZD 1	Cross Traffic	3	256	2 V
9	Axis Separator					
10	Actual Value	PZD 1	Input	2	336	14 V
11	Setpoint	PZD 1	Cross Traffic	3	256	1 V

AXES Detail PZDNo

Insert Axis Delete Axis Insert Slot Delete Slot

Master-Slave-Configuration

Master: (2) DP-Master
Station: SIMATIC 300(1)

Comment:

OK Cancel Help